







(D) Vor Montage bitte Gebrauchsanleitung lesen!

(I) Prima del montaggio leggere per favore le istruzioni per l'uso!

(F) Prière de lire le mode d'emploi avant de procéder au montage!


(GB) Please read the instructions of use prior to starting installation work!

BPW / BPF / BF2




BPW / BPF / BF2-L

1




BPW / BPF / BF2-L

2




BPW / BPF / BF2 - L

3




BPW / BF2-L

4a




BPF - L

4b




BPW / BF2-L

5a




BPF - L

5b




BPW / BF2 / BPF - L

6




➔ 12 BF2 BPW / BPF - L

7




BPW / BPF

8




BPW / BPF

9




BPF

10




BPF

11




BF2

12




BF2

13




BF2

14




BF2

15



BPF / BPW / BF2


16



BPF

17a


innen / intérieur / interno / inside



BPF

17b


außen / extérieur / all'esterno / outside



BPW / BF2

18a


innen / intérieur / interno / inside




BPW / BF2


18b


außen / extérieur / all'esterno / outside





BF2





PIN: 0000
123456789012345678
123456789012

→ Ersatzteil / Pièce de rechange / Parte di ricambio / spare part