

cod.619M0412




Istruzioni di montaggio
Assembly instructions
Instructions de montage
Montageanleitung
Instrucciones de montaje
Instrucțiuni pentru montare



IRSAP SPA 45031 Arquà Polesine (RO) Italy
Tel. +39 0425 466611 ; Fax +39 0425 466662
Website: <http://www.irsap.com>; E-mail: info@irsap.it




Numero Verde
800-252246

IR GROUP S.A.S. 7, rue du Pont à Lunettes
69390 Vourles (France)
Tel. +33 04 72 31 86 31 ; Fax +33 04 72 31 86 32
Web: <http://www.irsap.com>; E-mail: irsaphross@irgroup.fr
IRSAP-RHOSS Clima Integral, S.L. Oficinas y Almacén:
C/ Leonardo da Vinci, 4 Pol. Ind. Camí Rei
08850 GAVÀ (Barcelona)
Telf. +34 93 633 47 00 ; Fax +34 93 633 47 04
Web: <http://www.irsap.com>; E-mail: info@irsap-rhoss.com






Ø	Int.	T
20	272	370
	340	480
25	270	370
	360	480





(*):
ESEMPIO CON Ø20
EXEMPLE AVEC Ø20
EJEMPLO CON Ø20
BEISPIEL MIT Ø20
EXEMPLU CU Ø20














M	Int.	T
25x20	320	450
	400	550



1



4



5

6

7

8

9

9

